

Construction and function

CI Fuel Injection System
240/260 1976—

Section
2

Group
24

CI Fuel Injection
System
240/260

VOLVO

Contents

	Page
Introduction	1
General	2
Description of the CI-System	4
Function of the CI-System	
Cold engine starting	6
Engine warmup	7
Maximum load/acceleration	8
Cruising – part throttle	9
Engine shutdown	9
Warm engine starting	10
Function of CI-System Components	11
Air System	11
Air cleaner	11
Air flow sensor	11
Throttle	12
Idle adjustment screw	12
Auxiliary air valve	12
Fuel System	13
Tank pump	13
Fuel pump	14
Fuel accumulator	15
Fuel filter	15
Fuel distributor, 1976–1977	16
Line pressure regulator, 1976–1977	16
Line pressure regulator/check valve, 1978	17
Fuel control unit	18
Pressure regulator valves	18
Injectors	20
Control pressure regulator	20
Cold start injector	22
Thermal time switch	22
CI-System Electrical Circuits	23
CI-Fuel system wiring diagram	23
Fuel pump circuits	24
Cold start injector and thermal time switch circuits	24
Control pressure regulator and auxiliary air valve circuits	25
CI-Fuel Injection System	
240 1976	26
240 1977	27
Diagrams-fuel flow	28
Component location guide	
B21F	30
B27F	31

TP 12043/2

3000.04.80

Printed in U.S.A.

CI-Fuel System Components - B21F General

Introduction

The CI-Fuel Injection System is used on both the B21F, B27F and B28F engines (240—260 series vehicles).

To help simplify the presentation of information, this manual illustrates and outlines the basic system for the B21F. References are made to the B27F and B28F in those areas where components and/or operation differs significantly from that of the B21F engine.

NOTE: All reference to 240 and 260 models in the manual also apply to DL, GL, GLE, GT and Coupe as appropriate."


General

The B21F, B27F and B28F engines are equipped with the CI-Fuel Injection System (CI stands for Continuous Injection). This system is basically mechanical and contains one injection valve (injector) per engine cylinder.

The "CI" is derived from the fact that the injectors continuously inject fuel into the engine while it is running.

Fuel supplied to the engine is controlled by varying the flow to the injectors.

The purpose of the CI-System is similar to that for all other type fuel systems, that is, to store, transfer and supply fuel to each cylinder in the proper amount. This fuel is mixed with the incoming air in the ratios needed for various engine operating conditions.




121 947

A number of components, all working together, are used to enable the operation described above. (See illustration of CI-Fuel System Components on next page.)

To understand the operating principles of the CI-System the following must be known:

- Fuel combustion requires air. Proper burning of the fuel/air mixture is dependent on the mixture ratio.
- Nominal mixture ratio is 1 part fuel to 14 parts air by weight.
- Measuring the volume of air being supplied to the engine can be used to determine the amount of fuel needed.




121 948

6 cyl. shown


The basic principle of the CI-System is to continuously measure the air flow into the engine and use this information to control the amount of fuel provided to the engine. Incoming air and fuel flow are in fact regulated by the airflow control unit, which is the "brain" for the CI-System. This unit consists of the air flow sensor (A) and fuel distributor (B).

CI-Fuel System Components – B21F




Description of the CI-System


Refer also to "CI-System – Fuel Flow Diagram" at rear of this manual. Individual components are described in greater detail in the Section titled "CI-System Components".




121 950



121 951



121 952



121 953

Air flow to the engine is controlled by throttle (butterfly valve) position, engine speed and load.

During idle, air flow is regulated by the *idle adjustment screw (I)*.

Incoming air flows through the *air flow sensor (A)* consisting of air flow sensor plate (2) moving within the air venturi (1). The air flow sensor plate is attached to lever (3).

Air flowing through the venturi moves the air flow sensor plate in direct proportion to the air volume. (The greater the amount of air flowing through, the more the plate is moved.)

Amount of plate movement is transferred through lever (3) to control plunger (4) in the *fuel distributor (B)*.





Therefore, when the air flow sensor plate moves, the control plunger also moves.

The control plunger moves within a cylinder (barrel) containing metering slots (one slot per engine cylinder).

Plunger and cylinder together are referred to as *control valve*.

When the control plunger lifts in relation to air flow, it exposes the metering slots and fuel flows through them to the *injectors (K)*.

Restricted air flow to engine: Air flow sensor plate and control plunger move slightly. This exposes only a small portion of the metering slots, and thus a small amount of fuel passes through.



Increased air flow to engine: Air flow sensor plate and control plunger move a greater distance. This exposes a larger portion of the metering slots, and thus more fuel passes through the openings.

Fuel supplied to the engine depends entirely on the amount of slot opening. This provides the fuel regulation for the CI-System.

Adjacent to each metering slot is a diaphragm valve called the *pressure regulator*.

These pressure regulators maintain a constant pressure difference between the inlet and outlet sides of the metering slots.


With this pressure differential, fuel flowing through the slots is influenced only by the amount of slot opening.

Thus the fuel is distributed evenly between all injectors (engine cylinders).

The fuel distributor also contains a *line pressure regulator/check valve (1)* which maintains line feed pressure at approximately 4.9 kp/cm² = 70 psi.

Fuel pump (D) provides considerably more fuel than the engine may need. Pump capacity is approximately 100 liters (26 US gals.) per hour. Excess fuel is re-directed through the line pressure regulator (1) back to the tank.

Some 1976 car models and all models 77 and later are provided with a *tank pump (C)* situated in the fuel tank. This pump maintains fuel pressure in the fuel line from the tank to the main pump. Fuel pressure is approximately 20 kPa (0.2 kp/cm² = 3.0 psi). Vapor pockets in the line are thus eliminated.



A = Line pressure regulator/check valve
1978 models

125 900


A portion of the fuel under pressure is re-directed through a narrow passage (1) to the top of the control plunger. This "control pressure" acts against the force moving the air flow sensor plate.

Control pressure is regulated by the *control pressure regulator (G)* and normally goes up to $3.7 \text{ kp/cm}^2 = 53 \text{ psi}$. Surplus fuel is channeled (at atmospheric pressure) back to the fuel tank.

If the control pressure regulator becomes clogged, line pressure will be present in the control pressure circuit. This restricts upward movement of the control plunger and the fuel/air mixture will become lean.

Components described thus far have been the main ones in the CI-System. Other components in the system are used to adapt for various operating conditions.

Function of the CI-System



Cold engine

121 961


Cold engine starting

When the ignition switch is set to START position the tank pump and main fuel pump start operating immediately to make fuel available to the system at line pressure of $4.9 \text{ kp/cm}^2 = 70 \text{ psi}$. Pressure pulses caused by the pumps are smoothed out by the fuel accumulator.

Fuel filtration is provided by the fuel tank filter and the line fuel filter.

After filtering, the fuel is channeled to the fuel distributor, control pressure regulator and the cold start injector.

While cranking, the engine cylinders develop a vacuum which causes air at atmospheric pressure to flow through the intake system. This air passes through the air flow sensor and continues through the intake manifold, passed the auxiliary air valve/throttle valve and to the intake port.




Simultaneously, the movement of the airflow sensor plate is transmitted via connecting arm to the control plunger. Movement of the plunger exposes a portion of the metering slots and allows a quantity of fuel to travel towards the cylinder injectors. All injectors are opened by fuel pressure and fuel is continuously sprayed into the intake port areas.

Turbulent air and fuel both present at the intake port areas mix to form the air / fuel mixture which is drawn into the cylinder during each intake stroke of the pistons (intake valves open).

The *cold start injector (J)* supplies additional fuel to enrich the fuel / air mixture for easier starting. This injector is electrically operated and injection time is regulated by the *thermal time switch (L)*. At -20°C (-4°F) or colder, fuel is supplied for approximately 7.5 seconds. At higher temperatures the injection period gradually decreases and ends completely at $+35^{\circ}\text{C}$ (95°F) for the B21F engine and at $+15^{\circ}\text{C}$ (60°F) for the B27F and B28F engines. The injector operates only when the starter motor is engaged.

The spark plugs provide ignition of the mixture during the compression stroke of each cylinder. Pressure caused by burning and expansion of the compressed fuel air mixture provides the driving force to operate the pistons and thus the engine.

121 960




Warm engine

Engine warm-up

A cold engine has greater friction than one at operating temperature and thus requires increased idle rpm to prevent stalling. The *auxiliary air valve (H)* automatically provides increased air and fuel flow for fast idle with the throttle valve closed.


The air valve opening is controlled by a bimetallic spring which is heated by an electrical coil. The valve gradually closes as the spring warms up and is fully closed at $+70^{\circ}\text{C}$ (158°F).

121 962



Control pressure, cold engine

121 963




Control pressure, warm engine

121 964

During cold engine operation some of the fuel may condense and adhere to the inlet port and cylinder walls. This causes a leaner mixture than desired.

To compensate for leaner than desired mixture, the *control pressure regulator (G)*, lowers the control pressure during engine warm-up. Thus the movement of the control plunger becomes less restricted and additional fuel is allowed to flow through the distribution slots and enriches the mixture.

As the engine warms up the control pressure regulator gradually increases the control pressure and causes the fuel/air mixture to become normal.




121 965

Maximum load/acceleration

At maximum load (throttle fully open and low vehicle speed) air flow pulses into the inlet duct. This causes the air flow sensor plate to move beyond the "normal" position and thus moves the control plunger even higher. Additional fuel passes through the exposed slots and enriches the mixture to obtain maximum output.

The narrow passage (2) above the control plunger dampens air flow sensor plate movement caused by the air flow pulsations. Movement of the sensor plate during abrupt throttle changes is determined by the size of the constriction.



121 966


Because the intake strokes occur more frequently per revolution in a six cylinder engine, the pulsating air flow in the B27F is not strong enough to enable mixture enrichment.

The B27F and B28F control pressure regulator is designed to sense the vacuum in the engine intake manifold. (Exception: models with Oxygen Sensor Feedback System, "California" and "High Altitude" specifications). At maximum load, the vacuum in the manifold decreases and causes the control pressure regulator to lower the control pressure. This causes the control plunger to move further upward, enriching the mixture and thus enabling maximum engine output.

Cruising – part throttle

At cruising speed (throttle partly open and steady vehicle speed), air passing the air flow sensor plate causes it to move and hold at a given position. This results in the control plunger assuming a position relative to air flow and allows fuel to pass through the slots in amounts necessary to provide "normal" mixture.

Any small changes in throttle valve setting causes a corresponding change in the air flow sensor plate and control plunger position. Thus the volume of fuel/air mixture is changed without appreciably affecting the mixture ratio.



121 959

Engine shutdown

When the engine is shut down the fuel pumps stop operating and the line pressure drops rapidly to below injector opening pressure. The line pressure regulator then closes completely. Fuel is prevented from flowing back to the fuel tank by a check valve (1) in the line pressure regulator ('78 models) and non-return valve (2) on the main pump (and tank pump).

Fuel, at rest pressure, is stored in the system for an indefinite period. This pressure prevents vapor pockets from forming in the lines and facilitates restarting of a warm engine and operation under various extreme environmental conditions.

The accumulator (E) stores fuel under pressure and assures that fuel pressure will be maintained over a longer period.

Because the intake strokes occur more frequently per revolution in a six cylinder engine the pressure in the intake manifold is not strong enough to ensure mixture enrichment.

The BPT and BSC control pressure regulator is designed to ensure a constant pressure in the intake manifold. Enrichment is provided by the Oxygen Sensor Feedback System, "California" and "High Altitude" or "Rich" systems. At manifold load the vacuum in the manifold decreases and causes the control pressure regulator to lower the control pressure. This causes the control plunger to move further upward, enriching the mixture and thus enabling maximum engine output.

Warm engine starting

Operation of the fuel system for warm starts is similar to that for cold starts except:

1. **Fuel, at rest pressure, exists in the lines to provide instant fuel availability to the engine.**
2. The cold start injector operates for a shorter period or does not operate if engine temperature exceeds $+35^{\circ}\text{C}$ (95°F).
3. The auxiliary air valve is only partially open or is fully closed and inoperative if engine temperature exceeds $+70^{\circ}\text{C}$ (158°F).
4. The control pressure remains at "normal" thus restricting additional movement of the control plunger and maintaining normal fuel/air mixture.

Cruise - part throttle
At cruise speed the throttle body is open and steady vehicle speed is maintained. The air flow sensor plate senses it to move and hold at a given position. This results in the control plunger setting a position relative to the flow and allowing fuel to pass for the flow amount necessary to provide normal mixture.


Any small changes in throttle valve position cause a corresponding change in the air flow sensor plate and control plunger position. Thus the volume of fuel/air mixture is changed without greatly affecting the mixture ratio.

Engine shutdown
When the engine is shut down the fuel pumps stop operating and the line pressure drops rapidly to below injector opening pressure. The line pressure regulator then closes completely. Fuel is prevented from flowing back to the fuel tank by a check valve in the fuel pressure regulator. The injector and control valve (CV) on the main pump is a check valve.

Fuel at rest pressure is stored in the system for an indefinite period. This pressure prevents vapor pockets from forming in the lines and facilitates restarting of a warm engine and operation under various extreme environmental conditions.

The fuel regulator stores fuel under pressure and ensures that fuel pressure will be maintained over a longer period.

For warm starts the fuel system is designed to provide instant fuel availability to the engine. The cold start injector operates for a shorter period or does not operate if engine temperature exceeds $+35^{\circ}\text{C}$ (95°F).



Function of CI-System Components

Refer also to "CI-System Fuel Flow Diagram" at rear of this manual.

The CI-System is composed of two subsystems; air system and fuel system.

Operation of each component is explained below in detail in the order of air and fuel flow through the system.

Explanation of CI-System electrical circuit operation can be found in section titled "CI-System Electrical Circuits".




Illustration shows the air cleaner for the B21F


121 967

Air System

The air system contains those components necessary for cleaning, measuring, regulating and directing air into the engine cylinders. This includes air cleaner, *air flow sensor (A)*, throttle, intake manifold, *idle adjustment screw (I)* and an *auxiliary air valve (H)*.

Air cleaner

The air cleaner removes particles from the air which can damage the engine and contains a replaceable paper element filter.



121 968

Air flow sensor

The air flow sensor continuously measures air flowing into the engine and transmits this information to the fuel distributor.


This unit consists of an air venturi (1) and an air flow sensor plate (2) which moves in the venturi. The plate is attached to lever (3) which transmits the movement of the plate via flange (4) to the control plunger in the fuel distributor.

Weight of the sensor plate and lever is counter-balanced by counterweight (5).

Adjustment screw (7), attached to lever (6), can be used to adjust the CO content. The adjustment screw regulates the basic setting of the control plunger (CO-adjustment).


Differences in engine loads require appropriate changes to the mixture ratio. Design of the air flow sensor venturi (see illustration) provides the means for automatic mixture ratio compensation.

In the area where the venturi walls are steeper than the mid portion, the air flow sensor plate will lift higher per a given volume of air flow. This causes a richer mixture to occur during idling and at full load.



a = idle b = part load c = full load

121 969




121 970

Throttle

Air flow to the engine is regulated by the throttle to control engine speed. Increased air flow results in higher speed. Throttle movement is controlled directly by the accelerator pedal position.


NOTE: There is no direct mechanical link between the throttle valve and the air flow sensor plate.



121 971

Idle adjustment screw (I)

This screw located in a bypass line above the throttle regulates air flow to the engine when the throttle is closed (idle). Restricting the air flow in the bypass line causes lower idling speed while increased air flow raises the idle rpm.




- 1 Electrical cable
- 2 Bimetal spring
- 3 Return spring
- 4 Valve


121 972

Auxiliary air valve

This valve is mounted on the engine and is used to provide fast idle during engine warm-up. It consists of an air duct, valve and bimetallic spring.



When the engine is cold, the bimetallic spring forces the valve open and allows air to pass through the duct (full opens at -30°C (-22°F)).




After the engine has started, current flows through the electric wire wrapped around the bimetallic spring. Heat from the wire causes the spring to bend away from the valve. The return spring acts on the valve and closes off the air duct.

The valve becomes fully closed at $+70^{\circ}\text{C}$ (158°F) which is equivalent to running the engine for 5 minutes at an ambient temperature of 20°C (68°F).

Fuel system

The fuel system contains those components necessary for measuring, cleaning, regulating and distributing fuel to the engine cylinders. This includes; tank pump (C), fuel pump (D), pressure accumulator (E), fuel filter (F), fuel distributor (B), control pressure regulator / check valve (G), injectors (K), cold start valve (J), as well as fuel line and fuel tank.




Tank pump

Installed on some 1976 models and all models from 1977 on.

The tank pump containing a winged impeller is electrically operated and is used to maintain pressure in the line from the fuel tank to the main pump. This prevents potential vapor lock from forming in the line.


This pump operates at all times that the ignition switch is set to the ON or START position. Fuel is drawn into the chambers between the impeller wings that rotate within the stepped chamber. It is then forced into the line to the main pump.

A non-return (check) valve at the pump outlet prevents fuel from returning to the tank when the pump is not operating.




Fuel pump

This electrically driven roller-type pump feeds fuel under pressure to the CI-system. Pump operation begins when the starter motor engages or the engine is running.





As the pump motor spins, the rollers are forced outward by centrifugal force and ride against the eccentrically shaped pump chambers. Fuel is drawn into the cavities between the rollers and forced outward to the line under pressure.




If pump output is greater than the system need (pressure rises above a pre-determined value), built-in relief valve (2) opens. This allows the fuel to be circulated around the pump without a further increase in pressure.

The non-return (check) valve (1) on the outlet side prevents fuel from flowing back when the pump stops operating.

- 1 Inlet
- 2 Outlet
- 3 Accumulator housing
- 4 Diaphragm
- 5 Stop
- 6 Spring



108 198



108 989

108 988


Fuel accumulator

The accumulator dampens pump pulses and maintains rest pressure in the system for a prolonged period after the engine is shut down. (It also acts to quiet the pulsing sounds emitted from the pump.) Essentially the accumulator is a spring loaded diaphragm.

When a cold engine is started, a delay in pressure buildup is compensated for by the fuel stored under pressure in the accumulator chamber. During release of this fuel the diaphragm briefly returns to the unloaded position.

As the fuel pumps operate, pressure builds thus pumping fuel into the accumulator chamber and compressing the diaphragm and spring.

When the engine is shut down and the fuel pumps stop operating, fuel is maintained at "rest pressure". This pressure is held for an extended period due to accumulator spring pressure in combination with fuel stored in the chamber.




121 977

Fuel filter

The fuel filter traps most foreign particles before they reach components that could become clogged or damaged.

A paper element is used to filter the fine particles and a special mesh (l) traps any paper particles that may have broken loose from the filter itself. This is why the fuel filter is directional and must be properly installed in the line. An arrow is used to indicate direction of fuel flow.

1976-1977



This illustration shows a fuel distributor for the B27F 1976-1977. The only difference between this and the fuel distributor for the 4-cylinder B21F is the number of outputs for the injectors.


121 978

Fuel distributor

The distributor regulates and distributes fuel to the injector in direct proportion to the air entering the engine.

Major components in the distributor are:

1. *Line pressure regulator* – regulates line and rest pressure.
2. *Fuel control unit* – regulates and distributes fuel to the injectors.
3. *Pressure regulator valves (one for each injector)* – maintain a constant pressure differential ($1 \text{ kp/cm}^2 = 14 \text{ psi}$) between the fuel control unit input and output sections.




121 979

Line pressure regulator, 1976-1977

Functionally the regulator is a spring-loaded plunger.


Pressure is held constant (approximately $4.9 \text{ kp/cm}^2 = 70 \text{ psi}$) by controlling the amount of fuel passing through the returnline.

The dotted lines represent a passageway which allows fuel to pass that has leaked from between the control plunger and its cylinder in the fuel control unit.



121 980


When the engine is shut down (the pumps stop operating), line pressure drops to below opening pressure for the injectors. The line pressure regulator valve closes fully and maintains rest pressure of $1.7 \text{ kp/cm}^2 = 24 \text{ psi}$ minimum in the system.



Line pressure regulator/check valve


The CI system fuel distributor includes a two function regulator/check valve assembly(1).


Operation of fuel control unit (2) and pressure regulator valves (3) are not affected.



The assembly regulates line pressure and also prevents fuel from returning to the tank from the charged lines after the engine has been shut down. Rest pressure is thus maintained in the fuel system which provides positive starting capabilities under all environmental/engine temperature conditions.

No adjustments or maintenance is required during normal operation. Malfunction requires replacement of the entire fuel distributor as before.





108 202


Fuel control unit

This unit consists of a cylinder (1) with one metering slot (3) per injector. Control plunger (2) moves within the cylinder and is controlled by air flow sensor movement.

As the control plunger lifts, more of the metering slot(s) area is left exposed thereby allowing additional fuel to flow to the injectors.

Fuel under control pressure acts on the top of the control plunger to partially counteract the upward movement of the plunger.

Control pressure is regulated by the *control pressure regulator (G)*.




108 207

Pressure regulator valves

These valves maintain a constant pressure difference between the inlet and outlet sides of the slots regardless of the amount of fuel passing through the slots. This assures that the slot openings alone determine fuel flow to the engine injectors. Thus, fuel flow control is not influenced by pressure variations or by deviations in required opening pressure between each injector.


Each pressure regulator valve consists of two chambers separated by a diaphragm. The lower chambers (1) are linked to each other by means of channels and the inlet on the slots (see line pressure regulator illustration on previous page).

The upper chambers (3) are connected to the outlets on the slots and house a valve whose inlet area varies with the position of the diaphragm (2). Spring (5) is used to exert force on the diaphragm.




108 915

The forces above and below the flexible diaphragm act on it causing a shift in position according to the differential pressure. This shift occurs until a state of balance is achieved.



108 208



108 916

The pressure in the lower chamber is always equal to line pressure, that is approximately $4.9 \text{ kp/cm}^2 = 70 \text{ psi}$.

Pressure in the upper chamber is the sum of the fuel pressure plus spring pressure and when in balance with the lower chamber equals $4.9 \text{ kp/cm}^2 = 70 \text{ psi}$.


Because spring pressure is equal to $0.1 \text{ kp/cm}^2 = 1.4 \text{ psi}$, the fuel pressure must be $4.8 \text{ kp/cm}^2 = 68.6 \text{ psi}$.

Thus the fuel pressure difference between upper and lower chambers (inlet and outlet on the slot) is $0.1 \text{ kp/cm}^2 = 1.4 \text{ psi}$.

When the control plunger rises, the fuel flow through the slots increases. Pressure in the upper chamber thus increases forcing the diaphragm downward. This increases the fuel control unit opening to the injectors to maintain the pressure difference of $0.1 \text{ kp/cm}^2 = 1.4 \text{ psi}$.

The diaphragm regulates the opening in the fuel control unit to assure that the amount of fuel flowing from the upper chamber is equal to that flowing into the chamber.

Diaphragm movement is only a fraction of an inch.



121 981


Injectors

Fuel is injected continuously into the intake manifold while the engine is running. When the intake valves open the fuel is drawn into the cylinders.

Injectors contain a spring-loaded disc type valve that opens at fuel pressures of approximately $2.1\text{--}2.3 \text{ kp/cm}^2 = 37\text{--}51 \text{ psi}$. Check specifications for engine application.

Fuel is atomized as it exits the injectors.

The amount of fuel injected is controlled by the *fuel distributor (B)* as the injectors perform no regulating function.




Control pressure regulator B21F

121 982

Only B27F

- | | |
|-------------------|------------------------------|
| 1 Electrical coil | 5 Connection for hose to in- |
| 2 Bimetal spring | let duct |
| 3 Spring | 6 Spring |
| 4 Diaphragm valve | 7 Diaphragm |

Control pressure regulator diaphragm valve movement is regulated by a bi-metal spring.



Control pressure regulator B27F

121 983

Control pressure regulator

This unit is mounted on the engine and is used to adjust the fuel-air mixture for cold and warm engine operation.



During cold starts and while the engine is warming up, the regulator lowers the control pressure and causes the fuel-air mixture to become richer.

NOTE: For certain B27F engines, the control pressure also drops under maximum engine load (controlled by engine vacuum).



Exception:

Models with Oxygen Sensor Feedback System, "California" and "High Altitude" specifications.

NOTE: For B28F engines, the control pressure regulator differs from the regulator shown on these pages. Check engine specifications.



121 984



121 985

B21F and B27F engines:

When the engine is cold, the bi-metal spring bends downward and acts against the coil spring. The colder the engine the more the spring is compressed resulting in additional valve opening. This allows additional fuel to flow back to the tank and lowers the control pressure.

Lower control pressure allows increased movement of the air flow sensor plate and the control plunger resulting in a richer fuel-air mixture.

When the starter motor is energized and during engine operation, current flows through the heating coil wrapped around the bi-metal spring. The resulting heat buildup in the spring causes it to warp away from the coil spring and thus exert less pressure on it. Coil spring pressure is now allowed to act on the diaphragm, pushing the valve upward and causing the control pressure to increase.

From 1977, vehicles sold in high altitude areas are equipped with a control pressure regulator incorporating an altitude compensating device.

B27F engines only:


The control pressure regulator is connected to the engine intake manifold via a vacuum hose. At normal engine speed, intake manifold vacuum is greater, thereby assisting diaphragm upward movement. Diaphragm valve (7) is forced upward by atmospheric pressure and acts against the spring.

1977 B27F vehicles manufactured to "California" specifications should have the control pressure regulator connected to open air.


At maximum engine load (throttle fully open at low rpm), the intake manifold vacuum drops. This causes diaphragm valve (7) to move downward away from the spring allowing the fuel valve to open further. The resultant control pressure drop enriches the fuel-air mixture which is needed for maximum engine output.

As engine output decreases (reduced throttle) intake manifold vacuum increases and again allows the diaphragm valve to press against the spring (6). The diaphragm valve opening becomes smaller and the control pressure increases.

- 1 Solenoid
- 2 Return spring
- 3 Actuator
- 4 Seal
- 5 Nozzle insert



121 986



121 987

Cold start injector


The cold start injector is electrically operated and is used to supply additional fuel to the engine for cold starts. Injection time is controlled by a *thermal timer (L)*. When starting at -20°C (-4°F) or colder, fuel is injected for approximately 7.5 seconds. At higher temperatures the injection period decreases and ends completely at $+35^{\circ}\text{C}$ (95°F).

The injector operates only when the starter is energized and will function at each attempt to start the engine.

When current passes through the coil, magnetic action causes the actuator to be pulled upward and fuel is injected through the injector opening and into the intake manifold.

When the coil is no longer energized, the return spring forces the actuator against the seat and fuel is prevented from exiting the injector.

NOTE: Check specifications for model year and engine application.



121 988

Thermal time switch

The timer regulates cold start injector operation by varying circuit make/brake time according to engine temperature and length of starting cycle.

Electrical contact action is controlled by a bi-metal spring surrounded with a heating coil. Because the unit is located in the engine block it is also affected by engine coolant temperature.

When the engine is cold, below $+35^{\circ}$ (95°F), the contacts are closed and current can then flow to the cold start injector when starting the engine.

Current flow through the heating coil causes the bi-metal spring to heat and bend, thus opening the points and deactivating the injector.

Cycle time for this operation is directly related to engine temperature. The warmer the coolant the shorter the injection time.

NOTE: Check specification for model year and engine application.


CI-System Electrical Circuits

The wiring diagram below provides component identification and interconnection information for the CI-Fuel System electrical circuits.

Functional description of circuit operation is given in the pages that follow.


CI-Fuel System Wiring Diagram

1978—



125 905

1978—




Fuel pump circuits

When the ignition switch is set to the start position, pulsating DC voltage is applied to the ignition coil primary winding. This voltage is also applied to terminal 31b of the electronic pump relay as a signal voltage.

A pulse sensing circuit in the relay assembly is activated which energizes the pump relay via +12 volt control voltage (terminal 15). Current then flows from terminal 30 through the relay contacts to the fuel pump and tank pump via terminal 87.

125 906

1978—



Cold start injector and thermal time switch circuits.


The cold start injector and thermal time switch are operational only when the starter motor is energized.

The thermal time switch makes or brakes the circuit to the cold start injector depending on engine temperature and length of starting time.

During cold starts the contacts in the thermal time switch are closed allowing current to flow to the injector coil. This causes the injector valve to open and fuel is sprayed from the injector.

During warm engine starts, the contacts remain open and no fuel is passed through the injector.

125 907



125 908

Control pressure regulator and auxiliary air valve circuits


During cold engine starts and warmup, current flows from terminal 87b of the electronic pump relay to the control pressure regulator and auxiliary air valve.

Each of these units contains an electrical heating coil which acts on a bimetal spring thus regulating the operation time for each device.

CI fuel injection system 240/1976

Wire colors:	
SB	- black
GR	- gray
W	- white
R	- red
BR	- brown
Y	- yellow
BL	- blue
GN	- green

Approx wire sizes:	
0.75	mm ²
1.5	- 18 gauge
2.5	- 16
6.0	- 14
10.0	- 10
16.0	- 8



Fuse No. 5:

Relay, CI system

Bulb failure warning system, page 24

Turn signals, page 36

Instrument cluster, page 60

Fuse No. 7:


Fuel pump, CI system

Clock, page 62


Legend:

- A Auxiliary air valve
- B Thermal time switch
- C Relays
- D Ignition switch
- E Connector
- F Fuel pump
- G Starter motor
- H Fuse box
- I Control pressure regulator
- J Cold start injector
- K Air/fuel control unit


Starting engine




Engine running



Engine stalled (ignition on, but engine not running)



CI fuel injection system 240/1977



Fuse No. 5

- Instrument cluster
- Turn signals
- Relay, CI system


Fuse No. 7

Clock
Fuel pump


Legend:

- A Fuel feed pump
- B Thermal time switch
- C Fuse
- D Fuel pump
- E Connector
- F Ignition lock
- G Auxiliary air valve
- H Fuse box
- I Starter motor
- K Relays
- L Cold start injector
- M Control pressure regulator
- N Air/fuel control unit


Starting engine




Engine running



Engine stalled (ignition on, but engine not running)




CI-System Fuel Flow Diagram 1976-1977



B21F
1976-1977


- A Air flow sensor
- B Fuel distributor
- C Tank pump (1977-)
- D Fuel pump
- E Fuel accumulator
- F Fuel filter
- G Control pressure regulator
- H Auxiliary air valve
- I Idle adjustment screw
- J Cold start injector
- K Injector



B27F
1976-1977


CI-System Fuel Flow Diagram 1978

B21F
1978—




-  Air at atmospheric pressure
-  Air at vacuum
-  Fuel with line pressure of 490 kPa (4.9 kp/cm² = 70 psi)
-  Fuel at pressure of approx. 20 kPa (0.2 kp/cm² = 3 psi)
-  Fuel at injection pressure of approx. 330 kPa (3.3 kp/cm² = 47 psi)
-  Pressureless fuel
-  Fuel with control pressure at approx. 370 kPa (3.7 kp/cm² = 53 psi)

B27F
1978—




125 904

B21F CI-System – Component Location Guide



121 998

B27F CI-System – Component Location Guide



121 999



**VOLVO SUPPORTS VOLUNTARY
MECHANIC CERTIFICATION
BY THE N.I.A.S.E.
USA ONLY**

VOLVO

TP 12043/2

3000.04.80

Printed in U.S.A.

Printed in U.S.A.