


Design and Function

LH-Jetronic 2.4 — LH2.4



The circled numbers in the drawing refer to the same numbers in the following listing.

LH-Jetronic 2.4 (B230F)

- | | | |
|-----------------------------|--|--------------------------------|
| 3 Ignition switch | 131 Diagnostic unit | 217 Main relay |
| 7 Starter motor | 132 Idle valve | 218 Throttle switch |
| 10 Fuse box | 162 Lambda sond | 221 Coolant temperature sensor |
| 32 Connection at instrument | 211 Electronic control unit,
EZ116K | 223 AC pressure switch |
| 95 Cold start injector | | 225 Injectors |
| 97 Tank pump | 212 In—line fuse | |
| 100 Fuel pump | 214 Electronic control unit,
LH2.4 | |
| 112 Joint | | |
| 129 AC Relay | 215 Air mass meter | |

